

Personal GPS Tracker TL-406 Manual

1 Appearance

Waterproof with two-way communication, SOS alarm, fall down alert, auto tracking and precious positioning. It is suitable for children, elderly, lone workers, patients, and vehicles. You can implement real-time tracking via the mobile phone app or tracking platform.

2 Specifications

Content	Specs
2G	Europe 900/1800MHz
3G HSPA Bands	America B2/B4/B12 Europe B1/B8 Australia B1/B5
4G LTE CAT-1 Bands	Europe B1/B3/B7/B8/B20 America B2/B4/B12 Australia B1/B3/B5/B7/B8/B28
Dimensions	43x70x21mm
Weight	55.2g
Waterproof Level	IP67
GPS Sensitivity	Tracking -165dBm Re-acquisition -163dBm Acquisition -148dBm
GPS Accuracy	<10m
GPS Start Time	Cold start 36s Warm start 22s Hot start 1s
Battery Capacity	1100mAH
SIM Card Type	Nano Sim
Firmware Upgrade Mode	OTA/USB
Work time	Max 72hours
Charging time	3-4hours

3 Charging

Contact the charging interface by the magnetic USB cable.

4 Inserting a nano SIM card

Open the device with screwdriver, put SIM into card port in proper direction. Tighten the device to make sure it is waterproof.

Note: To avoid battery damage, ensure the SIM slot is closed before screwing back the device

5 Switching the device on and off

Hold the power button for more than 3 seconds until tracker vibrates. This indicates on/off.

6 Set the authorized phone numbers

You can set 8 phone numbers at most. Send command **123456A1**, **authorized phone number** via SMS, the device replies: 1 TEL OK! Authorized phone number.

Note: A1 means the first phone number, A2 means the second etc.. until A8

7 SOS Emergency Call

Hold SOS button until device vibrates. SOS alert will be triggered and will send message to phone numbers A1-A3 and call A1-A8

Note: If A1 misses the call, the device will automatically call the next until someone answers.

8 Making A Phone Call

Hold Call 1 button or (dial A4) or Call 2 button (dial A5) for 2 seconds, release when vibrates and the GSM or GPS indicators flash quickly. You can hand up the phone call by pressing SOS **Note:** To adjust the call volume, press Call1 to turn it up and Call2 to turn it down.

9 Answer the Phone Call

As default it will automatically answer after 4 rings. To change this send command 123456Q3,1 via SMS you can then pick up the call by pressing the function button and hang up with the SOS button

10 Listen-in Function

Send command 123456U1 via SIS, the device answers automatically and goes to listening in mode when you make a call to the device.

Note: The default setting is two-way audio (123456U0) Command of U1 and U0 cannot be used at the same time, you can send command 123456U1/123456U0 to switch it.

11 Fall Down Alert

Send command 123456KLXXX to set threshold, XXX is 3 digital number (000<xxx<255). 000 means to close the fall down alarm function and 255 means the most sensitive fall detection XXX is advised to be from 045 to 060. For example, send command 123456KL060 via SMS, the device will reply "Set Low G Threshold OK" then when fall down alert is triggered, the device will send a message to the first authorized phone number, then A2 etc.

12 Get the single positioning

Send command 123456F via SIS. The device will search the GPS signal to get the latest location.

13 Connect to our tracking platform

(1)Set APN, IP and port. Send command 123456CAPN,IP:Port via SMS
(2)Send command 123456D to turn on SPRS.
(3)Send command 123456B to get the IMEI number, then share the IMEI number with us. We will offer you an account for logging into the platform www.glotracking.com/m

14 Reset the Device

Send command RESET! Via SMS, the device will reset to factory settings and restart.

Cautions

(1)Don't put in over heated or overcooled placed
(2)Handle carefully, do not shake or vibrate
(3)Do not paint the unit
(4)Do not disassemble or refit the unit
(5)Please use the battery and charger provided only
(6)This product should be used in the normal condition of GPS signal and GSM signal. If not, it will result in the inability to locate or locate data that cannot be transmitted
(7)The product has position tracking and listen-in functions, the user must use it within the legal limit. Such as invasion of privacy.



Function	Command	Example
Set phone numbers	123456Ax,phonenumber	123456A1,18588955622 X: (1-8)
Delete phone numbers	123456Ax,D	123456A1,D X: (1-8)
Set call to two way call mode	123456U0	Default setting is 123456U0
Set listen in mode	123456U1	When you make a phone call to the device it will be listen-in mode
SOS mute call	123456U2	It will be listen-in mode when making SOS call
SOS audio call	123456U3	It will be 2 way audio call when making SOS call
Set whether the call needs to be verified as an authorization number	123456Q2,x	123456Q2,1 X:0=only authorization number can make a call to the device 1= device can answer any call
Set two-way call mode	123456Q3,x	123456Q3,1 X: 0= the device takes the initiative to answer the call 1= you can pick up the incoming call by pressing function button or hang up using SOS button
Turn on voice recognition	123456Q4,1	
Turn off voice recognition	123456Q4,0	The default is turn off
Set fall down alarm	123456KLxxx	123456KL045 XXX: Fall down threshold, 000<xxx<255, 000=close the fall down alarm function
Set low battery alarm	123456Nx,yy	123456N1,30 X:0=turn off 1=turn on YY: low battery threshold
Set fully charged Alarm	12346N2,x	123456N2,1 X:0 turn off, 1=turn on
Single positioning	123456F	
Set local time zone	123456Lxxy X= West, x=+ East	123456L+08 (default time zone is +08)
Set continuous tracking time	123456Mx,yyyz	123456M1,005M X: 0= turn off, 1=turn on YYY: set the time (001-255) Z: S=seconds, M=minute, H=hour
Turn on GPRS	123456D	Default is off
Turn off GPRS	123456E	

Rehab and Mobility Wholesalers

6-8 Imboon Street, Deception Bay
QLD, 4508
www.rehabandmobility.com.au
qld@rehabandmobility.com.au
1300 368 085



Warranty: 1 Year